# Setup Guide — P/2 DA4xi and P/2 DA6xi

#### Installation

The Extron P/2 DA4xi and P/2 DA6xi are distribution amplifiers taking one video input (VGA to QXGA) and distributing it to one buffered loop-through and three (P/2 DA4xi) or five (P/2 DA6xi) individually buffered outputs. To install and operate either unit, follow the steps below.



### Step 1

Ensure all devices are powered off or electrical cables are disconnected.

### Step 2

Choose a suitable location and mount the distribution amplifier on a table, in a rack, or under a desk.

### Step 3

Connect a computer source to the 15-pin HD female input connector of the distribution amplifier.

### Step 4

Connect four (P/2 DA4xi) or six (P/2 DA6xi) high-resolution display devices to the 15-pin HD output connectors of the distribution amplifier.

**NOTE** Output 1, which is labeled "Local Monitor" is used for DDC reference.

# Step 5

Power on the distribution amplifier.

# Step 6

Power on the displays.

# Step 7

Power on the source.

# **Troubleshooting**

If the video output is "soft" on any display, move the video gain switch on the rear panel to the up (1V) position.

# If no image appears:

- Check all the input and output video cables are connected and secure.
- Check all devices are receiving power.
- If the issue still persists, call the Extron support hotline.

Extron USA - West	Extron USA - East	Extron Europe	Extron Asia	Extron Japan	Extron China	Extron Middle East
Headquarters +800.633.9876 Inside USA / Canada Only +1.714.491.1500 +1.714.491.1517 FAX	+800.633.9876 Inside USA / Canada Only	+800.3987.6673 Inside Europe Only	+800.7339.8766 Inside Asia Only	+81.3.3511.7655 +81.3.3511.7656 FAX	+400.883.1568 Inside China Only	+971.4.2991800 +971.4.2991880 FAX
	+1.919.863.1794 +1.919.863.1797 FAX	+31.33.453.4040 +31.33.453.4050 FAX	+65.6383.4400 +65.6383.4664 FAX		+86.21.3760.1568 +86.21.3760.1566 FAX	68-991-50 <b>A</b> 02 09